




Step 1:
Strip off at least 25mm of jacket from end of cable.
NOTE: IDC is suitable for 22-24 AWG wires.




Step 2:
Insert the wires into the cap through the holes. Fix the wires to their correct positions based on the color code. (T568A/T568B)



Step 3:
Cut the excess wires off. The tips of the wires should protrude no more than 0.5mm.




Step 4:
Put the cap on the IDC tower. The arrows on the jack and the cap should face the same direction. Put the cap into position.



Step 5:
Close the jaws until fixed.


Disassembly Instruction:




Insert the screwdriver into the slot and rotate it to open the jaw.

120.0


90.0




Etape 1 :
Oter la gaine du câble sur une longueur de 25mm




Etape 2 :
Introduire les paires dans le guide fil en prenant soin de respecter le code couleur choisi.



Etape 3 :
Couper l'excédent de câble sur chacune des positions au plus près du guide fil.




Etape 4 :
Positionner le guide fil une fois préparé en alignant dans le sens des flèches (guide fil et connecteur) comme indiqué.



Etape 5 :
Rabattre les deux demi capots jusqu'à l'encliquetage complet.

Démontage



Pour déverrouiller le connecteur, insérer le tournevis comme indiqué.

120.0

90.0